

HANDS-FREE AIRTUBE HEADSET™

FOR MOBILE & SMART PHONES

gia™

HOW TO USE THE RETRACTABLE WIRE FEATURE:

1.



Pull from BOTH ends of retractable device to extend wire as needed.

2.



Do NOT pull from ONE SIDE or wire will tangle.

3.



After use, gently pull wire from both ends of retractable device and release. Wire will retract.

HELPFUL TIPS FOR USING THE RETRACTOR:

1. If wires tangle from misuse, pull both ends carefully but firmly until last position locks, then retract.
2. If wire isn't retracting smoothly, wire may be twisted at the center. Pull both ends until in last position, straighten wires, then retract.
3. The GIA Hands-Free Headset is very durable and if used properly, should not break. If wires are pulled incorrectly, the spool may become off center and the wire will not fully retract. The wire is not broken and can easily be re-centered. Pull both ends until they lock into last position. Gently slide retractor piece along wires to re-center, then retract.